

## Securitime Timer - Installation Instructions

The following image illustrates how to connect the timer, please refer to the user instructions to set up the timer once power, the input and the outputs have been connected. Please connect 12V or 24V DC.

