

Read all instructions before starting installation

GENERAL INSTALLATION INSTRUCTIONS

- 4 The selection of appropriate power supply cable is very important to ensure lock receives sufficient power to operate.
- 5 Connect flying leads (+) Red (-) Black. Note - other leads for connection of LED via plug in lead ***NOT FOR POWER INPUT***.
- 6 This product has been designed for use in weather protected areas and under normal circumstances does not require any maintenance. **DO NOT OIL OR LUBRICATE.**
- 7 This product must be used in conjunction with a quality floor spring or door closer to ensure positive realignment on closing.

