

# **GARDIS Extension Modules**

To increase the number of doors or equipment in the system, extension units must be purchased along with a license dongle to insert into the master unit. The available extensions are listed below.

Note: A maximum of 10 extension units **or** 10 Wireless locks may be used.

### **GARDIS 4 EXT**

Description: 4 door Extension Module

#### Part No. 5002-6005

- Uses RS485 for connection to the master unit
- 4 additional reader channels
- 4 fail over modes





## **GARDIS I/O EXT**

Description: 8 pin input/output extension module **Part No. 5002-6006** 

- Uses RS485 for connection to the master unit
- Suitable for use with lift control
- 3 fail over modes



### **Wireless IP Locks**


Description: Assa Abloy - Aperio AH30 1-8 Comms Hub **Part No. 2920-0555** 

- Uses RS485 for connection to the master unit
- Max of 10 IP locks

Description: Simons Voss - Smart Intego Gateway Node

#### Part No. 2920-0556

- Uses RS485 for connection to the master unit
- Max of 10 IP locks



# **License Dongles**

These are physical pin dongles that allow for easy licensing of extensions. Using the dongles, you can extend a system by the quantities listed below, in addition to those that are avilable with the master unit.

#### **GARDIS Web 10**

Description: To extend systems up to 10 doors

Part No. 5002-6010

### **GARDIS Web 20**

Description: To extend systems up to 20 doors

Part No. 5002-6020

### **GARDIS Web 44**


Description: To extend systems up to 44 doors

Part No. 5002-6044



# **Connecting a Master Controller**





#### Cabling Information

2 Conductors (2 pairs recommended) Maximum distance: 750m Cable Type: 0.6mm (SYT recommended)

**DS0182 - Issue 1**