



Mobile Personal Alarm

MPA

QUICK START USER GUIDE

OPERATION

The MPA can be triggered by:

- Pushing the large button on the front
- Pulling the neck cord out of its socket
- Activating the shock/tilt sensor (if enabled and switched on).

STATUS LIGHT

RED light:

Alarm being transmitted

Flashing GREEN light:

Movement detected

Flashing RED light:

Shock/tilt alarm activated (reset with magnet)

Flashing RED/GREEN:

*(following a button press)
Low battery warning*

INTRODUCTION

The Scope MPA is a versatile portable alarm device which can generate radio alerts either on demand from a user, or automatically in the event of a fall or collapse.

The functions available are pre-set by the supplier of the device and cannot be changed by the user.

RESET

The button alarm will repeat a preset number of times then self-reset.

The neck-cord alarm will continuously repeat until the cord is replaced.

The shock/tilt sensor can only be reset by holding a magnet to the left side of the MPA (see cover photo).

For more information and full technical details about this product please contact your supplier or visit our website:

www.scope-uk.com



SHOCK/TILT SENSOR

Please contact your supplier to find out if the accelerometer (shock/tilt sensor) has been enabled on your device.

If enabled, it can be switched on or off using a magnet (see cover photo). Holding the magnet to the side of the MPA for 3 seconds will cause the status light to go red followed by either a red or green flashing light.

A red flashing light means the sensor is now switched off.

A green flashing light means the sensor is now switched on.

A triggered sensor alarm is reset by briefly swiping the left of the MPA with a magnet (see cover photo).

WHO GETS THE ALARM?

Alarms transmitted by the MPA may be received by portable pagers, fixed receiver(s), or both. Those receivers may in turn be connected to a panic alarm, nurse call, or other system.

The MPA will have been set up by your supplier to work with whichever system is in use in your premises.

CHANGING THE BATTERY

If the battery is low the status light will flash red/green and a warning message will be sent to any pagers on the system whenever an alarm is transmitted.

Although the battery is replaceable it is a specialist product and should only be changed by your supplier or an authorised Scope dealer.

LICENSING

The MPA is licence-exempt in the UK as a Short Range Device.

For use in other countries please contact your supplier for advice.



R&TTE directive 1999/5/EC

EMC Directive (89/336/EEC)
EN 301 489-1 V1.4.1

Low Voltage Directive
(73/23/EEC) EN60950 : 2000

ETSI EN 300 220-1 V2.1.1

ROHS II Compliant

FCC CFR 47 PART 90.213
FCC ID: JRNUSAPENLINKA

A Declaration of Conformity can be obtained from Scope.